

Carbon Dioxide Removal from Flue Gas Using Microporous Metal Organic Frameworks (MOFs)

Annabelle I. Benin,¹ Paulina Jakubczak,¹ John J. Low,¹ Syed A. Faheem,¹
Ganesh Venimadhavan,¹ Ozgur Yazaydin,² Randall Q. Snurr,^{*2}
Antek Wong-Foy,³ Kyoungmoo Koh,³ Adam J. Matzger,^{*3}
Jian Liu,⁴ M. Douglas LeVan,^{*4}
Xiayi (Eric) Hu,⁵ Stefano Brandani,^{*5}
Richard R. Willis^{*1}

¹ UOP LLC, a Honeywell Company

² Northwestern University (*Chem E*)

³ University of Michigan (*Chemistry*)

⁴ Vanderbilt University (*Chem E*)

⁵ University of Edinburgh (*Chem E*)



24 March 2009

NETL CO₂ Capture Technology for
Existing Plants R&D Meeting
DE-FC26-07NT43092



A Honeywell Company

© 2009 UOP LLC All Rights Reserved

Business Units

Catalysts, Adsorbents
& Specialties
CA&S

Process Technology
& Equipment
PT&E

Renewable Energy
& Chemicals
RE&C

- Develop & deliver **innovative technologies**
- Design, engineer, license & service **process technology**
- Manufacture **catalysts, molecular sieves, adsorbents** & specialty catalytic products equipment
- Provide **consulting services** for the optimization & technical management for the hydrocarbon industry
- Solve problems with technology & transfer that technology to customers

Technology Licensing



Performance Improvement Partner



Leading Supplier of Catalysts & Molecular Sieve Adsorbents

Project Overview


Funding Highlights and Dates

Total budget: \$2,802,200

- **DOE/NETL share = \$2,230,672**
- **UOP share = \$571,528**

2 April 2007 to 31 March 2010

Project Organization





Our Collaborative Approach

■ Make MOF Materials

- Team ideas *UM and UOP*
- Literature compounds



a) MIL-53 from Ferey, et al, *JACS* 2002, 124, 13519.

b) UMCM-1 from Koh, et al, *ACIE* 2008, 47, 677.



■ Model Interesting Materials



- Hydrolysis *UOP*
- Isotherms *NU*
- Maximum theoretical surface areas



HKUST-1 from Williams, et al, *Science* 1999, 283, 1148

■ Evaluate materials





- Adsorptive properties *VU and UE*
- Hydrothermal stability *UOP*



- Develop a MOF-based CO₂ capture process
- Design a pilot study to evaluate process:
 - performance
 - economics
- Year 1 *(ended 31 March 2008)*
 - synthesize and screen up to 50 MOFs
 - evaluate and establish baseline adsorption equilibrium characteristics for MOFs in general
- Year 2 *(ends 31 March 2009)*
 - down-select to ~10 best candidate MOFs to optimize
 - determine water and other contaminant effects
 - begin scale-up and forming
- Year 3 *(ends 31 March 2010)*
 - further optimize one or two MOFs
 - determine adsorption kinetics
 - develop process design and economics analyses

Technology Fundamentals/ Background

MOF construction




some graphics from Yaghi, et al, Nature, 423 (2003) 705

Properties: Zeolite versus MOF

similarities to zeolites:

- synthesis conditions
- good yields
- crystalline
- tunable hydrophil(phob)icity and acid(basic)ity





rho

ZMOF-rho from Eddaoudi, et al, *Chem Comm* 2006, 1488

differences from zeolites

- lower temp stability (up to 450 °C reported)
- much higher SA and PV per gram
- more unobstructed gas diffusion
- much more diverse chemistry
 - many more metals/ metal clusters available
 - organic linkers can contain functionality



sod


ZIF-8 from Yaghi, et al, *PNAS* 2006, 103, 10186

material	surface area, sq m/g	crystal density, g/cc	% free volume	pore size, Å	stability, deg C	CO2 heat adsorp, kJ/mol
NaX	700	1.44	49	7.4	> 700	50
IRMOF-1	3800	0.62	79	12	400	15

Utilize MOFs in a Pressure Swing Adsorption (PSA) process to remove CO₂ from coal-fired power plant flue gas

- **Vacuum PSA system with multiple beds and five basic steps**
 - adsorption, co-current depressurization, counter current depressurization, purge and re-pressurization carried out according to a complex algorithm
- **Feed T = 100 - 120 °F**
- **Feed P = 19 psia**
- **Pressure of CO₂ to compression= 0.5 psia**
- **Temperature of CO₂ to compression= 100 - 120 °F**

Schematic of the PSA process




Same process steps apply to a PSA Unit with any number of adsorbers.

- **Environmentally friendly**
- **Less parasitic power required for the capture process**
 - However, higher compression power required to compress up from the sub-atmospheric VPSA outlet to pipeline pressure

- **Effect of steam, SO_x and NO_x on the MOF material**
- **Selectivity for CO₂ over Nitrogen**
 - Amount of N₂ that needs to be compressed along with the CO₂
 - The necessity for separating N₂ from CO₂ before further compression and transport
- **Large vacuum pumps to compress the CO₂ from the outlet of the VPSA**
- **Pressure drop across the VPSA beds**

Progress and Current Status



Key MOF Properties

Status 31 Dec 2008

high adsorption capacity

so far, so good

easily regenerable

so far, so good

good adsorption/ desorption rates

OK unless pores small

high selectivity

*especially CO₂ over
nitrogen and water*

stable to O₂, SO_x, NO_x

in progress

Combinatorial Heat Treatment Unit (HTU)

Max T	900 °C
Max steam	50 %
# of Steam conditions	6
Max flow	400 ml/min
Max loading	~2 mL max loading
Physical	48 Quartz reactors 48 temp controls 6 independent pumps Gas blending downflow
Software	Controls pumps and collects flow data Controls blending system and collects data

Semi-Automated Zero Length Column (ZLC)

T range	30 - 400 °C
P range	(atmospheric) P _{CO₂} in He 0.001 – 0.1 bar
Sample size (equilibrium)	10 – 15mg
Sample size (kinetic)	1 – 3mg
Sample size (breakthrough)	gram
Software	Labview control (semi-automated)
DID detector (long time decay for desorption)	
TCD detector (for CO ₂)	
Mass Spec detector (binary data)	
High speed mass flow controllers	




Rubotherm

T range (regen)	600 °C
T range (test)	10 – 400 °C
P range (test)	2 torr – 100 bar
Vacuum	1×10^{-3} torr
Weigh accuracy	+/- 1.0 μ g
Sample size	70 – 90mg




Supernanoporous MOFs at 195K

CO₂ Adsorption



unfortunately, 195K performance is not predictive for 298K

HKUST-1: Ambient to High Temperature




q_{st} of CO₂ on HKUST-1 : 23 ± 1 kJ/mol

$$\ln(P) = \frac{-\Delta_{vap}H}{nR} \left(\frac{1}{T} \right)$$



Case Study: ZIF-8

- **Make it** *UOP*
- **Model it**
 - Isotherm *NU*
 - Hydrolysis *UOP*
- **Evaluate it**
 - Adsorptive properties *VU and UE*
 - Hydrothermal stability *UOP*




140 °C, 1d

DMF




Yaghi et al, *PNAS* 2006, 103(27), 10186-10191.

ZIF-8: CO₂ Isotherm Model Matches Experiment



CO₂ adsorption experiment and simulation match

ZIF-8: Model Predicts Hydrothermal Stability





E of transition state: 55.7 kcal/mol
Zn-N bond broken

Zn-O bond forms

E of rxn : 22.7 kcal/mol


prediction: very hydrothermally stable

High-Throughput Hydrothermal Stability Testing




As-synthesized samples:
solvent exchanged
dried (elevated temp)
loaded
activated (elevated temp) in N₂ overnight
steam 0 - 50%, 40 - 400C, 2 hours
unload in air, XRD in air


ZIF-8: 300 °C Treatment for Two Hours



hydrothermally stability confirmed in the laboratory



Steam Stability Map



Summary


- A wide variety of MOF materials successfully synthesized and evaluated
- Theory correlates well with experimental results
 - Experimental and simulated isotherms match nicely
 - Hydrothermal stability predictions trend with steaming studies
 - ***Recent results helping guide experiments***
- Progress has been made on CO₂ Capture with MOFs
 - Team hitting on all cylinders

Path forward

- Collect more CO₂ data in moisture-containing streams
- Begin contaminant (NO_x, SO_x etc.) testing
- Explore new synthesis space

Success Criteria Summary

Moderate steam stability End of Phase II performance targets are 15 wt% CO₂ capacity at 20 °C at up to 2 atmospheres pressure. A minimum stability target will be retention of 75% CO₂ capacity after exposure of material to 3-7 mole% steam at 100 °C for 2 hours.



Phase III Objective:

Demonstrate one or more MOF materials that meet performance targets and have sufficient stability to carry into pilot testing

Phase III Performance Targets:

15 wt% CO₂ capacity at 40 °C at up to 1.25 atm pressure

Minimum Stability Target:

Retention of 75% CO₂ capacity after exposure up to 15 mole% steam at 150 °C for up to 24 hours

Ends 1 April 2010

- (A) A MOF optimized for flue gas 
 - Meets material performance targets for CO₂ removal
 - Synthesized in sufficient quantity to support a pilot study
- **(B) Commercialization study report** 
- **(C) Process design report**
 - Design details for a CO₂ removal from flue gas process using the optimized MOF
 - Pretreatment requirements and process conditions included
- **(D) Pilot study design report**
 - Design details for a two-stage pilot study comprising:
 - ◆ Preliminary pilot study in stand-alone pilot plant
 - ◆ Field study operating on slipstream from an operational plant
- **(E) Economic design report**
 - Detail on the inputs, assumptions and results of estimating the costs and energy requirements for a commercial scale CO₂ separation unit using the MOF-based adsorption process

Acknowledgements

This project is supported by the U.S. Department of Energy through the National Energy Technology Laboratory, under Award No. DE-FC26-07NT43092. However, any opinions, findings, conclusions, or recommendations expressed herein are those of the author(s) and do not necessarily reflect the views of the DOE.

Dave Penner
Dave Lesch
Pete Coughlin
Ganesh Venimadhavan
Mark Davis
Jenny Abrahamian
Larry Raney
Mary Ann Vanek
Jason Davis
Doug Galloway
Steve Dunne
Gary Malott
Kurt Vanden Bussche

